

Perfect-Machine Dish Wash & Perfect- Rinse Aid

Detergent For Dish Washing Machines



Two products have to be fixed to the automatic dosing pump of the dish washing machine to dose chemicals. This will provide a complete wash

and gives a good finish to the material. Dish washing machine has to operate in 60°C for washing and 90-95°C for rinsing mode. The tank water has to be changed in regular intervals to maintain the high standards.

Using Instructions

- Wash all the material with running water to remove all organic matters
- Stack all the items to the machine keeping sufficient space for washing
- Take out after washing and allow it to dry on its own
- Do not wipe or touch the washed items which can cause contamination

Features and Benefits

- The product is completely biodegradable
- Fast action & easy to use
- Works even with hard water

Safety Instructions

- Use gloves when handling the concentrated product
- Only for automatic dosing operation and not for manual use
- Keep out of reach of children

Active Ingredients

Surfactants | Emulsifiers | Emulsions

First Aid

Inhalation : None

Ingestion : None

Skin : None

Eyes : Rinse with clean water and take medical advice if irritation persists

Pack Size

5L



Store in a cool dry place, do not expose to direct sun light

Chemicals to Avoid : None



See the World in Green

Manufactured & Marketed By

BioNutri International (Pvt) Ltd

No. 06, Arthurt's Place, Angulana Station Road, Angulana, Moratuwa. Sri Lanka

Tel: +94 11 2611481 /482 | Fax: +94 11 2611181 | E-mail: info@bionutri.lk | Web : www.bionutri.lk

ISO 9001:2015 & GMP Certified Company by SLSI